



# LevelPro PR-7100

ADVANCED LIQUID LEVEL SENSOR

## PRODUCT USER MANUAL



# Table of Contents

<b>Quality Assurance Statement</b> .....	<b>2</b>
<b>ISO9001 accreditation</b> .....	<b>2</b>
<b>Terms of Warranty</b> .....	<b>2</b>
<b>Background information</b> .....	<b>3</b>
<b>Level measurement using a gas purge system</b> .....	<b>3</b>
<b>Sensor Description</b> .....	<b>5</b>
<b>Installation</b> .....	<b>6</b>
<b>Sensor installation</b> .....	<b>6</b>
<b>Tube connection</b> .....	<b>7</b>
<b>Sensor electrical connection</b> .....	<b>8</b>
Digital (SDI-12) Mode Electrical Connection .....	10
Digital (RS232) Mode Electrical Connection .....	11
Analogue Power Mode Electrical Connection - Voltage.....	12
Analogue Mode Electrical Connection – 4-20mA Current Loop.....	12
<b>Operation</b> .....	<b>14</b>
<b>Manual Mode</b> .....	<b>14</b>
<b>Analogue Output Mode</b> .....	<b>15</b>
<b>Digital Output Mode</b> .....	<b>16</b>
SDI-12 Output.....	16
RS232 Output.....	18
<b>Menu Functions</b> .....	<b>19</b>
Main Menu Structure.....	20
Display Menu .....	22
Datum Menu.....	24
Settings Menu.....	26
<b>Specifications</b> .....	<b>38</b>
<b>Product Return Form</b> .....	<b>39</b>

# Quality Assurance Statement

## ISO9001 accreditation

ESS Earth Sciences is currently an AS/NZS ISO9001:2008 certified organisation.

This certification is evidence that sound practices are used to get high quality instrumentation to your organization within a reasonable time interval. Standard practices are used for all areas of manufacture, beginning with the efficient procurement of incoming orders, right through to shipment.

Stringent quality assurance procedures are applied to all aspects of manufacturing, including the calibration of scientific instruments against NATA traceable references. Every sensor is accompanied by a test and calibration certificate that can be used as reference information as well as evidence of sensor accuracy.

## Terms of Warranty

The warranty covers part or complete replacement, repair or substitution of new instrumentation that has failed in part or completely within the warranty period. While every effort has been made to supply robust and user friendly instrumentation, the warranty does not cover instruments incorrectly installed, misused or operated in conditions outside those specified. The warranty does not cover shipment costs for instrumentation, installation or removal and, under no circumstances whatsoever, indirect or consequential losses caused by the failed instrumentation.

ESS Earth Sciences believes the warranty conditions to be fair and just and in accordance with standard business practices worldwide. ESS Earth Sciences reserves the right to arbitrate any warranty issues and will ensure that warranty issues are treated with the highest standards of professional conduct.

At ESS Earth Sciences we believe your investment in our products and services is a good decision and we will therefore ensure all your requirements are met at all times, both now and in the future.

# Background information


## Level measurement using a gas purge system

Gas purge systems have been used for many years in the hydrographic industry, well before electronic pressure sensors were introduced. They provide a convenient method to measure water levels accurately without having to install sensitive instruments in water.

The principle of operation is simple. A gas purge system provides a close to static pressure condition inside a capillary tube. One end of the tube is installed under water, while the other is connected to the gas purge system and pressure sensing instrument, out of the water. To ensure water does not enter the submerged tube end (when the level increases), an inert gas (typically nitrogen) is pumped into the tube by the gas purge system. The flow rate is maintained extremely low, just enough to prevent water from entering the tube, while providing a static pressure condition. The pressure required to overcome the hydrostatic (head of water) pressure is therefore same at both ends of the tube. By measuring the pressure at the dry end, the pressure at the submerged end is determined. A simple calculation using pressure to head of water conversion is then made to determine water level.

A practical gas purge system consists of several components. Firstly a compressed gas is required for which low cost dry nitrogen is typically used. Nitrogen bottles are filled are at high pressure, around 15-20MPa (2000psi) hence a bottle regulator is used to reduce the pressure to around 400kPa (60psi). Gas is fed into a gas purge regulator also called a constant differential flow regulator as it regulates the flow with varying backpressure. Next, a capillary tube is required to carry the gas to below the water surface. One end is connected to the flow regulator output, while the other is installed under the water surface to be measured. The gas purge regulator is adjusted to produce a very low flow rate of approximately 50 cc/hour. The flow of gas is so low that it is always laminar producing only negligible friction effects. This is important as it results in almost zero pressure difference between tube ends, even if small internal diameter tube is used. Lastly, a pressure sensor is connected to the dry tube end for measuring the pressure in the system. Pressure is converted to level using liquid density and a standard for kPa to level conversion.

The levelpro PR-7100 is designed to operate with all types of gas purge systems. A typical layout configuration is shown below.




# Sensor Description

The levelpro PR-7100 sensor is a microprocessor based pressure sensor, calibrated in kilopascals (kPa). Measurement is converted to a number of units including linear distance (metres and feet) of liquid head, volume and flow. A four line LCD display (dot matrix type) shows measurements, short messages and instructions for in-built functions. Configuration is via a keypad on the front display panel. Two multi-pole connector sockets are available for electrical connection and a ¼" tube fitting for pneumatic connection to the gas purge system.

The sensor enclosure houses all electronic and electromechanical components and provides IP67 protection. A 0.2µm hydrophobic filter is fitted on the bottom of the sensor to allow atmospheric pressure regulation inside the enclosure, thereby eliminating barometric pressure variations.

Every PR-7100 sensor is supplied with a signal cable, power cable and stainless steel wall mounting bracket, conveniently packaged in a sturdy, recycled cardboard carton. The figure shown below shows the basic sensor layout and major components.



# Installation

## Sensor installation

The levelpro PR-7100 must be wall mounted using the supplied stainless steel wall mounting bracket. Screws are supplied for fitting the bracket to the sensor. You must provide 2 wall mounting screws suitable for the wall material being used.

Equipment required:

- levelpro PR-7100
  - Signal and power cables
  - Connecting tube, ¼" nylon
  - Wall mounting bracket and screws
  - 2 screws for mounting to wall – to suit wall material
  - Phillips head screwdriver, medium
  - Adjustable spanners, 150mm minimum
- } supplied with new sensor

Some points to consider:


- The sensor must be installed out of rain, snow and direct sunlight. Air borne moisture and dust will not affect the sensor operation.
- A gas purge system must be installed according to the manufacturer's installation instructions. The system should ideally be installed close to where the sensor will be installed (within 1.5 meters (60")).
- Single or dual line gas purge systems can be used, provided they operate according to specifications and there is one available ¼" tube port.
- The gas purge system sensor port must be fitted with an isolation valve to ensure the sensor can be isolated during gas purge system maintenance (capillary line purging).

Typically, a site shelter that offers protection from at least the above should be provided.

Choose a suitable vertical wall section within, no more than 1.5 m (60") from the gas purge system. Also ensure that the display can be read easily without staff having to strain to achieve a suitable viewing position.

Fit the sensor bracket to the wall section using appropriate screws as shown below. If mounting the bracket onto a metal wall section, pilot holes should be pre drilled before fitting the bracket. Use plastic wall plugs and appropriate screws when fitting brackets to masonry walls.

Place the sensor onto the bracket and secure using the supplied screws.



# Tube connection

The ¼" black nylon tube included with the levelpro PR-7100 is used to connect to the gas purge system. It must be fitted to the sensor pressure port and appropriate connection point on the gas purge system.

**You MUST use two spanners to connect the ¼" tube to pressure port to prevent the mating tube fitting from rotating. The tube nut size is 9/16" and bulkhead fitting nut size, located at the bottom of the PR-7100, is 5/8".**

**To prevent damage to the PR-7100 always install an isolation valve in the connecting tube or at the purge system. Use the valve to isolation the sensor during capillary tube purge cycles.**

The ¼" tube may be shortened or extended. Doing so has no significant effect on sensor performance as the pressure inside is static only (no flow).

- Connect the ¼" brass nut to the PR-7100 pressure port by hand until tight.
- Using two adjustable spanners, tighten the nut half a turn further.
- Connect the other end of the tube to the gas purge system. A fitting must be provided that accepts ¼" OD tubing. It is recommended to use a compression ferrule type fitting where the ferrule is crimped onto the tube end when the nut is tightened. Either brass or plastic fittings can be used. Using a spanner matching the nut size, tighten the nut onto the fully inserted tube. Typically only one and a half turns are required to crimp the ferrule.

**Tightening the nut more than the recommended amount will result in eventual leaking of pressure. Do not tighten the nut more than necessary.**

**Crimp ferrule type fittings do not require the use of a sealing compound, unless specified in instructions. The fitting used must be suitable for the ¼" nylon tube as any variation in size will result in possible leaks. Please refer to your fitting supplier's instructions before proceeding.**


The ¼" tube can be extended using a ¼" tube union (or adapter for another size tube) and a length of suitable tube. Ensure any fittings are installed to the manufacturer's recommendations to ensure gas tight seals are formed. The quality of gas seals on fittings can be checked with a detergent and water solution. When applied to the outside of fittings, any leaks will result in the formation of many small bubbles around the area of the leak. Off the shelf leak test solutions are available from your gas fitting shop.

# Sensor electrical connection

The levelpro PR-7100 sensor is supplied with 2 cables with connectors fitted to match the sensor sockets on the bottom of the sensor. The larger connector is used for connection of all signal lines while the smaller connector and cable is used only for providing 12VDC power. The following tables provide details of all signal and power connections.

## **Cable Conductor Designation – multi-pole connector**

1	RED	Battery power +
2	BLACK	Battery power -
3	BLUE	Ground
4	BROWN	RS232 Rx (receive data)
5	WHITE	RS232 Tx (transmit data)
6	DARK GREEN	RS232 handshaking
7	YELLOW	SDI-12 data
8	VIOLET	High Level alarm output
9	GREY	Low Level alarm output
10	PINK	Analogue enable
11	ORANGE	Not used
12	RED-WHITE	Not used
13	BLACK-WHITE	Not used
14	ORANGE-WHITE	Not used
15	BROWN -WHITE	Not used
16	GREEN-WHITE	Not used – do not connect
17	LIGHT GREEN	Analogue output (voltage)
18	BLUE -WHITE	Analogue output (current)



Plug with cable

Front View

### **Battery Power +**

Use this connection to supply power to the sensor. Power must be between +10 and +15V DC. Supply is reverse bias protected using a diode. When power is applied, the sensor switches on briefly to indicate power connection. Thereafter the ON button must be pressed to obtain readings or configure the sensor for operation. To automatically output measurements on analogue output, you must connect Switched Power Enable (PINK pin 10) to power supply +ve.

### **Battery Power -**

Use this connection to supply power return (-ve) to the sensor. This input is directly connected to sensor analogue and digital ground.

### **Ground**

Connected directly to sensor analogue and digital ground.

### **RS232 Rx**

This connection is an input that allows the sensor to accept RS232 commands from a controlling device (DTE). All RS232 parameters are fixed except the baud rate. Input must be via a true RS232 driver that can provide the correct signal levels.

### **RS232 Tx**

The PR-7100 sensor outputs RS232 data at 5.0V EIA/TIA-232 levels. All RS232 parameters are fixed except the baud rate. Select the desired baud rate through the Settings menu. Only one digital output can be selected at any one time.

### **SDI-12 data**

The SDI-12 data line is used exclusively for SDI-12 bi-directional communication. This line remains at high impedance until the sensor responds to a correctly addressed command at which time a 0-5V logic data signal is transmitted to the

SDI-12 controller in accordance with SDI-12 protocol version 1.3.

### **High Level Alarm Output**

This connection is will be driven from 0V to 5V when the preset threshold for the "high" level alarm is exceeded. See page for alarm setup instructions.

### **Low Level Alarm Output**

This connection is will be driven from 0V to 5V when the preset threshold for the "low" level alarm is exceeded. See page for alarm setup instructions.

### **Analogue Enable**

Connect this line to supply +ve (RED). It effectively forces analogue output whenever power is applied to the sensor. This feature is required for data loggers and recorders that provide a switched power output whenever measurements are taken. When power is removed the sensor turns off completely.

### **Analogue Output - Voltage**

This connection will output voltage (0-1V or 0-2.5V) in proportion to measurements with reference to ground. A high impedance voltage input equipped recorder can be used to measure the output on this connection. Select voltage output by configuring the sensor through the Settings menu. Only one analogue output can be selected.

### **Analogue Output - Current**

Use this connection if 4-20mA output signal is desired. It is a ground referenced current *source* that can be connected to current measuring devices. For 12 volt operation, the load resistance must not exceed 450ohms (900 ohms for 24 volt). Select current output by configuring the sensor through the Settings menu.

## Cable Conductor Designation – 2 pin power connector

1	RED	Battery power +
2	BLACK	Battery power -



### Battery +12Vdc - RED

The red wire is used for +12Vdc battery supply and is protected by a reverse protection diode to prevent sensor damage if the polarity is accidentally reversed.

### Ground 0Vdc – BLACK

Power supply ground connection.

## PR-7100 Sensor Output Configuration


The following details show sensor electrical connections for interface to specific recorder/ controllers (using appropriate sensor configuration settings).

### Digital (SDI-12) Mode Electrical Connection

To operate the PR-7100 sensor in SDI-12 mode, only 3 connections are required. The DC power cable is not required as the SDI-12 recorder/ controller will provide continuous power to the sensor. While power is supplied, the sensor is in a sleep state that causes very little power draw. Incoming commands will be processed only if the sensor address programmed during configuration matches the command address character. In SDI-12 mode the sensor will only respond to fully compliant SDI-12 commands that include the “break” character.

The table below shows the pin-out for an ESS SDI-12 connector used for connecting sensors to SDI-12 enabled recorder/ controllers.

PR-7100	Colour	designation	5-pin male plug
1	RED	Supply +ve	A
3	BLUE	Ground	C
7	YELLOW	SDI-12 data	B




## Digital (RS232) Mode Electrical Connection

To operate the PR-7100 sensor in RS232 mode, 3 terminations are required. The DC power cable is required as the RS232 DTE does not provide continuous power to the sensor. While power is supplied, the sensor is in sleep mode where very little power is drawn. An incoming, correctly addressed RS232 command will cause the sensor to wake and process the command. No handshaking is required as the PR-7100 sensor wakes upon an incoming RS232 command. During command processing the sensor display remains off.

The table below shows connection to a 9 pin female “D” connector that connects directly to a computer serial port.

PR-7100	colour	designation	RS232	9-pin D female
5	WHITE	RS232 Tx	RxD	2
4	BROWN	RS232 Rx	TxD	3
3	BLUE	Ground	Ground	5



2 pin power cable

1	RED	Supply +ve
2	BLACK	Ground


## **Analogue Power Mode Electrical Connection - Voltage**

The PR-7100 sensor can be configured to output analogue signals in two modes, continuous and switched. For continuous mode the sensor is powered (and ON) continuously and remains in this state indefinitely. Use this mode to connect to recorders/ controllers that require a continuous signal such as PLCs. You must connect the PINK (pin 10) wire to supply + (RED, pin1) to force continuous output.

For switched power mode, connect the sensor the same way (as shown below). The recorder must be able to switch sensor power on and off as required. While switched on, the sensor operates as a continuously powered sensor. While switched off, the sensor draws zero power. Configure the sensor to output either 0-1V or 0-2.5V.

The table includes pin-out for an ESS analogue connector used for connecting sensors to analogue input equipped devices.

<b>PR7100</b>	<b>colour</b>	<b>designation</b>	<b>3 pin male plug</b>
1	RED	Supply +ve	A
3	BLUE	Ground	C
17	LIGHT GREEN	Voltage signal output	B
10	PINK	Analogue Enable Connect to Supply +ve	A




## **Analogue Mode Electrical Connection – 4-20mA Current Loop**

The PR-7100 sensor can be configured to output analogue signals in two modes, continuous and switched. For continuous mode the sensor is powered (and ON) continuously and remains in this state indefinitely. Use this mode to connect to recorders/ controllers that require a continuous signal such as PLCs. You must connect the PINK (pin 10) wire to supply + (RED, pin1) to force continuous output.

For switched power mode, connect the sensor the same way (as shown below). The recorder must be able to switch sensor power on and off which provides the power switching control. While switched on, the sensor operates as a continuously powered sensor. While switched off, the sensor draws zero power.

The table includes pin-out for an ES&S analogue connector used for connecting sensors to analogue input equipped devices.

PR-7100	Colour	designation	3 pin male plug
1	RED	Supply +ve	A
3	BLUE	Ground	C
18	BLUE-WHITE	Current signal output	B
10	PINK	Analogue Enable Connect to Supply +ve	A




# Operation

## Manual Mode

In manual power mode the sensor will take a level measurement and display it on the LCD display. Connect the 2 pin DC power cable to a 12V battery and sensor DC power socket.

Once power is connected to the sensor display shows (serial no. example only)



To obtain a measurement from the sensor:

Press



Display shows



To switch off, do not press any keys for 25 seconds. The sensor will automatically switch off thereafter or revert to another power mode.

You may also press



twice to switch the sensor off.

Display shows



Or the sensor will revert to another power mode

If the sensor is configured to continuous

Analogue power mode, display shows:



# Analogue Output Mode


In analogue output mode the sensor will take a level measurement and output a corresponding analogue voltage or current signal (depending on configuration). While switched or continuous power is applied with the Analogue Enable terminal connected to supply +ve, analogue output will be active continuously and updated as level changes occur.

While switched DC power is applied,  
the display will show:



To display the current measurement:

Press  Display shows



To switch off displayed value and revert back to Analogue Output Mode:

Press  twice. Display shows



Or simply wait for around 25 seconds. The unit will automatically switch back to Analogue Power Mode, as this is the prevailing mode.



*Analogue Output Mode always takes preference over Manual Mode. If the display is activated to show a reading while in Analogue Output Mode, the analogue output will not be interrupted.*

*Analogue output is available and stable after one second from the time switched power is applied. Switched power is typically removed after a reading has been attained. However it may be permanently applied to allow continuous analogue output used for devices requiring continuous signal such as PLCs. In doing so, continuous power consumption will result (see Specifications).*

*Any incoming SDI-12 or RS232 commands with an address matching the sensor address will be processed as highest priority. This ensures digital sensor data is unaffected while users are configuring the sensor or viewing measurements on the display.*

# Digital Output Mode

The levelpro 6150 provides digital output as either SDI-12 or user configurable RS232.

## ***SDI-12 Output***

To obtain a reading from the levelpro PR-7100 sensor in SDI-12 mode, it must be connected to a fully compliant SDI-12 controller device (SDI-12 protocol version 1.3).

In SDI-12 mode the sensor is permanently powered by the 12Vdc supply from the recorder/controller or through the dc battery power cable. Incoming SDI-12 commands will only be processed if the preceding address matches the set sensor address. A correct SDI-12 command received will invoke a sensor response according to the protocol as summarized below.

The SDI-12 command/ response sequence causes the sensor to switch on, respond to the command and switch off. As the sequence takes less than 1 second, there is no visible activity on the display.

 **If the sensor was started in manual or analogue power mode, a correctly addressed SDI-12 command will be processed as priority and override all other modes.**

## SDI-12 Command Set

Command	Response	Description
?! Eg. ?!	a 1 <CR><LF>	reveals sensor address sensor address is "1"
aI! Eg. 1I!	a13ccccccmmmmmmvvvsssss 118ESandS 6150 11220202	sensor identification
aM! Eg. 1M!	attn 10301<cr><lf> 1	buffers new measurement address 1, 030s measurement time, 1 data field, service request (1) sent when reading is available
aD0! Eg. 1D0!	apd.ddd 1+1.234 1+0001.234	returns buffer contents or measurement. leading zeros ON
aR! Eg. 1R!	apd.ddd not implemented 1+1.234 in version 1.21 1+0001.234	returns new measurement without D0! Command leading zeros ON
aAb! Eg. 1A2!	ar 21	change sensor address from 1 to 2
a	= sensor address	1 character
b	= new sensor address	1 character
ttt	= measurement time (secs)	3 characters %
n	= number of data fields	1 character
p	= polarity ( + or -)	1 character #
r	= return code (1 = all ok)	1 character
dd.ddd	= measured data	variable *
ccccccc	= Vendor ID	8 characters
mmmmmm	= sensor model	6 characters
vvv	= sensor firmware version	3 characters
sssss	= sensor serial number	5 characters

Leading zeros can be switched off and on through the *Settings – Communications – SDI-12* menu (see examples above). When switched on, the response from the 6150 sensor is always of fixed length, no matter the value. When leading zeros are off, the string length can vary according to the actual sensor output

```
1+0001.234      leading zeros ON
1+1.234         leading zeros OFF
```

# Polarity sign, whether + or – will always be included in response.

% The 6150 sensor has a variable measurement time depending on the measurement sequence parameters programmed in *Settings – Pump Settings* and if averaging is used (averaging implemented in version 1.21).

## ***RS232 Output***

Every PR-7100 sensor has an RS232 interface fitted as standard and is accessible using the designated wires in the signal cable. A 9 pin “D” connector, suitable for direct connection to most RS232 equipped communication equipment, can be factory fitted to allow easy connection. The PR-7100 sensor is a Data Communication Equipment (DCE) device and can be directly connected to Data Terminal Equipment (DTE) which includes modems, computers and telemetry systems.

### **Communication parameters:**

To communicate to the PR-7100 sensor via RS232, the DTE must be configured with the parameters shown below. No handshaking is required as the PR-7100 wakes upon incoming commands. The sensor baud rate is adjustable through the Settings menu.

Baud rate	= 1200 to 115000 bps
Parity	= none
Data bits	= 8
Stop bits	= 1

When sending RS232 commands, you must send the <carriage return> character at end of command strings.

# Menu Functions

When the sensor is switched on and a reading is being displayed, pressing any button (except ON) will enter the menu mode. In this mode the configuration of the sensor can be adjusted.

To obtain a measurement from the sensor:

Press  Display shows 

Press any other key to enter the menu mode



To navigate through the menus, use the following:


Use  and  keys to scroll through menu items.


Use  to enter into a sub-menu item or confirm and save a change.

Use  to revert back to the previous menu level or cancel an operation.

Pressing  while in the highest menu level will cause the sensor to switch off completely or revert to the previous power mode.

# Main Menu Structure





## Display Menu

Access the display menu by pressing any button except ON while the sensor is showing measurements.

Display will show

Press  to enter submenu

```
>Display
Datum
Settings
Password
```

or

Press  to move cursor

```
Display menu:
>Display Level
Units meter
```

**Display:** shows the currently displayed parameters when readings are taken.

**Units:** shows the currently displayed unit when readings are taken.

### Display menu - Display

Press  to enter

```
Select Display:
Level
Use Up/Dn to change
```

Press  or 

```
Select Display:
Volume
Use Up/Dn to change
```

**Level:** Selecting this parameter outputs a linear distance of liquid level

**Volume:** Selecting this parameter outputs a volume of liquid in accordance with a particular vessel shape.

Press  on the selected parameter to save the setting

### Display menu - Units

Press  to set parameter

```
Select unit for:
>Level
Volume
```

Press  or 

Each parameter has different units. Use this menu to select which parameter you want to change the units of measurement for.

## Display menu – Units – Level

Press  to set units

```
Level unit:
  m
Use Up/Dn to change
```

Press  or 

```
Level Units:
  Psi
Use Up/Dn to change
```

- mm all measurements are in millimeters using kPa to meters conversion
- m all measurements are in meters using kPa to meters conversion
- psi raw pressure output in pounds per square inch
- kPa raw pressure output in kilo Pascals
- in all measurements are in inches using kPa to feet conversion
- ft all measurements are in feet using kPa to feet conversion

## Display menu – Units – Volume

Press  to set units

```
Volume unit:
  m3
Use Up/Dn to change
```

Press  or 

```
Volume unit:
  gal
Use Up/Dn to change
```

- lit all measurements are converted to liters using selected tank shape
- m3 all measurements are converted to cubic meters using selected tank shape
- gal all measurements are converted to imperial gallons using selected tank shape
- kl all measurements are converted to kiloliters using selected tank shape

To save press 

```
Volume unit:
  Psi
Change saved!
Use Up/Dn to change
```

## Datum Menu

Sensor measurements can be referenced to a known level called datum offset. Two types of datum offset calculations are available as shown below. Access the datum menu by pressing any button except ON while the sensor is showing measurements.

Display will show

Press  to enter submenu

```
Display
>Datum
  Settings
```

or

Press  to move cursor

```
Datum menu:
>Enabled      No
Type         ABS
Value        +0.000
```

Enabled: set to YES to add datum value to reading.

Type: shows the type of datum used.

ABS Datum offset value is added to all readings.

REL Reading is taken. Datum is subtracted from reading and result is added to reading. This has the effect of forcing the current reading to be the same as the datum offset. Use this when entering exact staff gauge reading for water level measurement

Value: This is the datum offset value to be used in the calculation.

### Datum menu - Enabled

Press  to enter

```
Datum enabled ?
                No
Use Up/Dn to change
```

Press  or 

Press  to save parameter setting

### Datum menu - Type

Press  to enter

```
Datum type:
      Relative
Use UP/Dn to change
```

Press  or 

```
Datum type:
      Relative
Change saved!
Use UP/Dn to change
```

Press  to save

### Datum menu - Value

Press  to enter

```
Datum value(m)
      +0000.000
Dn-move, UP-change
```

Press  to change sign  
or

```
Datum value(m)
      -0000.000
Dn-move, UP-change
```

Press  to move one  
character to the right

```
Datum value(m)
      +0000.000
Dn-move, UP-change
```

Press  to increase digit

```
Datum value(m)
      +1000.000
Dn-move, UP-change
```

Example only.

Continue this process to adjust all digits. Once finished,

press  to save the new value.

```
Datum value(m)
      +1000.000
Change saved!
Dn-move, UP-change
```

Note: Datum values only apply to digital output (SDI-12 or RS232). Analogue output (voltage or current) is not affected by the datum value. Datum for analogue output is typically applied within the recorder/ controller to which the sensor is connected.

## Settings Menu

The Settings menu is used to configure the sensor for the desired operation and includes functions to set up analogue and digital output as well as housekeeping functions. Each Setting menu item is described in detail in the following sections.

To access the Settings menu it must be unlocked first by entering a password (see Main Password, page 31). By default, the Settings menu is unlocked.

Press  to enter submenu

```
Settings menu:  
>Analogue  
Alarm  
Communication
```

### Analogue

Use the analogue menu to set the type and range of analogue output. Two types are available, current and voltage. The full scale analogue output can be adjusted, effectively re-ranging the sensor. Full scale adjustment must be set for level, volume and discharge separately.

Press  to enter submenu

```
Analogue menu:  
>Output  
F/S(m):      +10.000  
F/S(m3):     +0.0E+00
```

### Settings – Analogue – Output

Use this menu to select either current (4-20mA only ) or voltage output. Select the span for the type of analogue output by entering the respective submenus.

Press  to enter submenus

```
Analogue output:  
>Type:      Current  
Span (mA):  4-20mA  
Span (V):   0-2.5V
```

Use  to change to Voltage output and press  to save

## Settings – Analogue – F/S(m)

Use this parameter to assign the full scale level, pressure, volume or flow for analogue output. The value selected here will be that represented by 20mA (current) or 1V/ 2.5V (voltage). Enter the value desired in the next submenu.

Press  to enter submenu

```
F/Scale (m):
+0010.000
Dn-move, UP-change
```

Press  to change to sign/ value

Press  to move one digit to the right. Press  to save.

Change the volume full scale ( F/S(m<sup>3</sup>) ) and discharge full scale ( F/S(m<sup>3</sup>/s) ) in the same way. Please note that discharge is not implemented in version 1.22.

## Alarm

A digital output provides alarm control for external devices. Output is at 0V when off and at 5V when active. This is a low current driver capable of driving high impedance external circuitry only.

Press  to enter submenu

```
Alarm menu:
>Alarm use: Disabled
High confis
Low confis
```

Enable or disable the alarm as required

```
Alarm usage:
Disable
Use UP/Dn to change
```

Set the high alarm trigger level  
and reset level in the next menu

```
High settings:
Trigger      +0.000
Reset        +0.000
```

Set the low alarm trigger level  
and reset level in the next menu

```
Low settings:
Trigger      +0.000
Reset        +0.000
```

Use both high and low alarms to set an alarm window. You must however ensure the high trigger and reset values are always higher than the low alarm values or the alarm may never trigger and/or reset.

## Communication

The Communication menu is used to configure digital output. Both RS232 and SDI-12 settings can be adjusted as shown in the following menus.

Press  to enter submenu

```
Communication menu:  
>RS232  
SDI-12
```

### Settings – Communication – RS232

Only the baud rate can be adjusted for RS232 communications. All other parameters remain fixed as shown below:

**No. of data bits:** 8  
**No of stop bits:** 1  
**Parity:** none

To set RS232 baud rate:

Press  to enter submenus

```
RS232 settings:  
>Baud rate: 9600
```

Set the baud rate compatible with the DTE device to which the sensor is connected. The possible baud rates are shown below:

- 1200
- 2400
- 4800
- 9600
- 19200
- 38400
- 57600
- 115000

Use  or  to change  
baud rate, press  to save

```
RS232 baudrate:  
9600  
Change saved!  
Use Up/Dn to change
```

## Settings – Communications – SDI-12

The SDI-12 settings menu can be used to enable SDI-12, set sensor address and configure the output data format.

Press  to enter submenus

```
SDI-12 settings:
>Enabled      No
Address      0
Data format
```

Change the status to “Yes” to activate SDI-12 communications. You cannot use RS232 output in this mode, however, this does not affect analogue output which can be used simultaneously, as previously configured.

### Address

Press  to enter submenus

Use  or  to change

```
SDI-12 address:
0
Use Up/Dn to change
```

### Data Format

Use this menu to change the SDI-12 output data format. This feature is particularly useful when recorders require a particular format to ensure data is received correctly at all times. Leading zeros ensures the data string is always of a fixed length while the number of decimal points can be changed to allow output of very large or very small numbers.

Use the respective menus to set leading zeros off or on and set the number of decimal points between 0 and 4.

Note: The PR-7100 is able to output numbers up to 8 digits. When outputting large numbers (level in mm or inches, volume in litres etc), set the number of decimal places to 0 or 1. Similarly, set the number of decimal places to 2,3 or 4 when outputting small numbers.

## **Averaging**

The Averaging menu allows users to configure the sensor to take several readings that are averaged. The averaging process outputs the average reading of a pre-programmed number of readings.

Press  to enter submenus

```
Averaging menu:
>Enabled          No
Mode              STD
Settings
```

### **Averaging – Enabled**

Select YES to enable averaging output.

### **Averaging – Mode**

Select standard averaging (STD) for typical averaging whereby a number of readings are added then divided by number of readings at the end of the process. Select Running (RUN) for producing running average that takes the last number of readings to produce an averaged reading every consecutive reading. This function is only available for PR-7100 sensors, not 6150 sensors.

Press  to enter submenu and  to change

### **Averaging – Settings**

This menu allows users to change the averaging parameters as required. There are two parameters, sample interval and number of samples. The total averaging time is the product of sample interval (in seconds) and no. of samples. For running averaging the averaging time is the same as the sample interval ( PR-7100 only).

Press  to enter submenu

```
Averaging Settings:
>Sampling Interval 1
No. of samples     60
```


### **Sample Interval**

Change the sample interval between 1 and 60 seconds. The sample interval is the time between readings in seconds. When selected, the averaging process forces the sensor to take level readings at this interval. The number of readings taken depends on the programmed number of readings (see No. of Samples).


**No. of Samples**

Select the number of samples for averaging between 2 and 60. Number of samples is the number of individual level readings the sensor will take before outputting an averaged reading. Total averaging time is the number of samples x sample interval (minimum 2 seconds, maximum 3600 seconds).

Standard Averaging – sensor takes a number of readings, adds all readings together and divides total by number of readings. This produces an averaged reading even if some or all readings vary substantially. Use this setting to measure tidal levels with waves superimposed onto desired sea level reading. Once reading is output, a new averaging interval begins.



Running Averaging – sensor takes a number of readings, adds all readings together and divides total by number of readings as per Standard Averaging. In standard averaging the process begins anew once the averaged reading is output for the first time. For running averaging and output is generated after each sample interval using the latest no. of samples. This way an averaged reading is output much faster after every sample interval (1 to 30 seconds). The sensor remains on continuously in this mode as this is a continuous output.



When averaging is enabled the main display will show that the reading is averaged. Running average is only available for PR-7100 . For example:

```
Level
(Ave:STD)
+43.756 m
```

or

```
Level
(Ave:RUN)
+43.756 m
```

## **Density**

When measuring level in liquids of density other than fresh water, a density factor can be programmed into the sensor to ensure pressure to level conversion remains accurate. For this sensor a relative density is assumed whereby freshwater (ultrapure) has a density of 1.0000.

Liquid density is the ratio of weight to volume. Fresh water is lighter than seawater, therefore seawater has a higher density. Some liquids other than water have a density less than 1. Simply enter the density of the liquid in the above menu. The readings taken thereafter will be automatically converted to the correct level.

## **Conversion**

The conversions menu is used to set the type of conversion used by the sensor to provide a calculated output.

### **Setting – Conversion – Level**



Use the level conversion menu to select kPa to distance conversion factor. All conversions are based on mm/kPa units.

Type: Select between a Standard and user defined conversion


Standard: If a STD conversion type is used, this submenu allows selection the standard used to convert kPa to millimeters water.

Standards:	Australian	102.15mm/kPa	British:	101.97 mm/kPa
	Sydney:	102.07 mm/kPa	Europe:	101.85 mm/kPa
	Melbourne:	102.04 mm/kPa	Equator:	102.25 mm/kPa


User defined: If a user defined type is used, this submenu allows entry of a non standard conversion in mm/kPa.

**Settings – Conversion – Volume - Cylinder**

Vertical cylinder (tank) is oriented as shown. Enter diameter (d) of the tank only. Level sensor will calculate tank volume based on measured height of liquid. For bubble tubes installed with end fitting above tank floor, use Datum menu to adjust volume.




For horizontally oriented cylindrical tank, enter diameter (d) and length (L) as shown. Ensure internal dimensions are used only. For bubble tubes installed with end fitting above tank floor, use Datum menu to adjust volume.




**Settings – Conversion – Volume - Box**

Box shaped tanks have vertical sides as shown. Enter length (L) and width (W) of the tank only. Level sensor will calculate tank volume based on measured height of liquid. For bubble tubes installed with end fitting above tank floor, use Datum menu to adjust volume.



**Settings – Conversion – Volume - Hopper**

This is an inverted pyramid shape commonly used in the process industry. Enter length and width dimensions in reference to height (H) . Level sensor will calculate tank volume based on measured height of liquid. For bubble tubes installed with end fitting above tank floor, use Datum menu to adjust volume.



## Screen

Use this menu to adjust screen settings.



The display backlight can be switch on an off using this menu.



By default the cursor is a flashing block. Use this menu to change it to underline if desired.



Display contrast can be adjusted in this menu between 1 and 7.

## Password

By default the settings menu can be accessed at all times. However users have the facility to password protect the settings menu to prevent unauthorized access. Once a password has been enabled in the settings menu, this menu is only available after the password is entered to unlock it. To unlock the Settings menu you must enter the correct password consisting of 4 numbers between 0 and 9. This must be done in the main menu.

Once password is entered press OK. If correct:


```
Enter password:
 1234
PIN accepted!
Dn-move, UP-change
```

or if incorrect:

```
Enter password:
 4321
PIN rejected!
Dn-move, UP-change
```

To lock the Settings menu again, enter the password again until it is accepted.


To change the password and enable/ disable you must get access to the Settings menu.



To change password use the up and down




buttons and press when finished to accept the new password.




The password menu allows you to enable or disable a password used to protect the sensor settings from unauthorized access. When in the Main Menu, the password must be entered to allow access to the Settings menu only. All other menus are freely accessible.

If password is disabled:




If password is enabled:




To unlock the Settings menu you must enter the correct password consisting of 4 numbers between 0 and 9.

Once password is entered press OK. If correct:



or if incorrect:



To lock the Settings menu again, enter the password again until it is accepted.

## Diagnostics

The diagnostics menu provides details of basic internal sensor parameters. While these provide information only, they are very useful while diagnosing technical difficulties when setting up the sensor. The calibration date parameter provides the date of last factory calibration.

Press  to enter diagnostics menu

```
Datum
Settings
Password
>Diagnostics
```

→

```
Diagnostics Menu:
>Last cal date
Firmware version
Supply voltage
```

```
Diagnostics Menu:
>Last cal date
Firmware version
Supply voltage
```

→

```
Last cal date:
Last calibration
date is
2006-01-18
```

Shows date of last calibration (yyyy-mm-dd)

```
Diagnostics Menu:
Last cal date
>Firmware version
Supply voltage
```

→

```
Firmware version:
Firmware version is
1.21
```

Shows currently loaded sensor firmware version

```
Diagnostics Menu:
Last cal date
Firmware version
>Supply voltage
```

→

```
SUPPLY voltage:
SUPPLY voltage is
+12.465
```

Shows current supply voltage available to sensor.

```
Diagnostics Menu:
Firmware version
Supply voltage
Sensor temperature
_
```

→

```
Sensor temperature:
Sensor temperature
is +21.000 (C)
```

Shows current internal sensor temperature

## Pump Settings

The PR-7100 does not have a pump system connected. This menu is only available when the PR-7100 is embedded in the 6150 pumppro.

```
PumpPro 6150 not
Connected. Press
<esc> to return
```

## Settings - AutoZero

Autozero is used to counteract long term sensor drift due to sensor ageing. The expected drift is typically very small and is due to thermal stress relief of silicon strain gauge components

```
Settings menu:
Diagnostics
Pump Settings
>AutoZero
```

Press  to enter submenu

```
AutoZero menu:
Offset 0.000%
>Apply offset? No
Set offset
```

Offset shows the amount of offset that was added to bring the atmospheric pressure reading back to zero. This value is automatically adjusted by the sensor after the Autozero is carried out.

You are able to select whether or not to use the offset. If you select "No", any offset value will not be added to the sensor reading. Selecting "Yes" will add the offset shown above.

Press  to enter submenu

```
Apply offset:
No
Use UP/Dn to change
```

When back in previous menu,

Press  to enter submenu

```
AutoZero menu:
Offset 0.000%
Apply offset? No
>Set offset
```

Press  to AutoZero

```
AutoZero:
Set Pressure to
Zero then press OK
<esc> to cancel
```

```
AutoZero:
Please wait...
```


```
AutoZero:
AutoZero Set!
Press ESC
```



**Ensure pressure is set to zero before performing AutoZero function.**

# Specifications

<b>Range:</b>	10, 20, 35, 70 meters freshwater (15, 30, 50 and 100psi) Non-standard ranges are available
<b>Units:</b>	kPa, psi, feet, inches, meters, centimeters, flow and volume units based on above
<b>Accuracy:</b>	Combined linearity/hysteresis/temperature compensation error over 0-50°C range: < ±0.15% of full scale for standard ranges
<b>Resolution:</b>	Analogue: 12 bit Digital: 16 bit Display 0.1mm water
<b>Temperature range:</b>	operating: -5°C to +55°C Storage: -20°C to +70°C
<b>Response Time:</b>	from standby: 0.25s to full accuracy from power up: 1s to full accuracy
<b>Type:</b>	Piezo resistive differential pressure sensor vented to atmosphere (gauge type)
<b>Output Options:</b>	Analogue: 4-20mA current, 3 wire loop (up to 600 ohm load @12V DC) 0-1 Volt or 0-2.5 Volt, 100 ohm impedance Digital: SDI-12 data protocol version 1.3 RS232C data Simultaneous digital and analogue output
<b>Tube Connection:</b>	¼" BSP female fitting standard with a selection of other tube fittings available
<b>Power Supply:</b>	10-15V DC unregulated Standby @12V: <10 mA Active @12V: <120mA backlight on plus current loop if used <25mA backlight off plus current loop if used
<b>Surge Protection:</b>	Inputs/outputs protected against transients by a secondary protection circuit that can absorb up to 1.5kW for 1ms.
<b>Enclosure:</b>	IP67 rated
<b>Display:</b>	4 line x 20 character LCD (7 x 5 dot matrix) with backlight, extended temp. range
<b>Weight:</b>	0.85kg



# Product Return Form

As part of our Quality Assurance initiative, and to improve response time, we request that the forms below are completed in as much detail as possible for product returns.

<b>OPERATOR INFORMATION</b>			
Name and contact details			
Company			
Date/Time			
Logger Site			
Location of product			
<b>PRODUCT INFORMATION</b>			
Model			
Serial number			
S/W version number(s)			
H/W version number(s)			
<b>SOFTWARE USED</b>			
Download program			
Remote or Local download			
Other software used			
<b>CONFIGURATION</b>			
Logger			
Length of tube			
Last logged values			
Measurement interval			
<b>SITE</b> - Describe site. Is unit in protective hut or enclosure? List any other sensors which are used at the site. Estimate cable length to sensors			
<b>POWER SUPPLY</b>			
Battery			
Voltage / Capacity			
Internal/External			
Solar/Mains charger			
Measured battery volts			
Solar Panel			
Voltage/Capacity			
Regulator make / model			
Switching/Linear regulator			
Mains supply			
<b>COMM PORT</b>		SDI-12 port	4-20mA
<b>EARTHING</b> -Describe any special earthing arrangements in place.			

<p><b>DESCRIPTION OF PROBLEM</b></p> <p>How did the problem manifest itself?</p> <p>Weather conditions while fault occurred (especially temperature)</p> <p>What commands were being used (SDI12 or serial)? <i>If possible, list the exact commands used, and the sequence. List the commands sent through the logger</i></p> <p>What action was taken to get the unit going again?</p> <p>Have you noticed anything in common with the last time there was a fault?</p> <p>Was the unit permanently disabled, or is the fault intermittent?</p> <p>Is this the first time the fault occurred?</p> <p>Is there anything unusual about this site compared to other sites?</p> <p>Is there any other equipment or facilities (e.g. local power lines) which could cause interference?</p> <p>Please list any other issues relating to the site or the fault.</p>	
---	--

# DELIVERING WATER MONITORING SOLUTIONS

## 2600 Turbidity Sensor

The 2600 Turbidity sensor is a miniature backscatter nephelometer that detects turbidity and suspended solids in water. Applications include rivers / streams / irrigation runoff water quality, sediment transportation, aquaculture, waste water quality, EPA compliance monitoring.



## PumpPro 6150

The 6150 combines an air compressor with an PR-7100 level sensor to create a highly reliable all-in-one water level sensor capable of measuring up to 70m of water head – more than twice the range of traditional bubbler systems.



## EC1600 Salinity Sensor

Reliability, accuracy, and consistency. The EC1600 brings wide range and high accuracy readings not previously achievable with toroidal electrical conductivity sensors, while avoiding the reliability and accuracy drift issues associated with contact-type EC sensors.



## Dipmeter

The Water Level Indicators Dipmeters are typically used to measure the depth of water levels in boreholes, standpipes or observation wells.



141 Palmer Street  
Richmond VIC  
3121 Australia

T: +61 3 8420 8999  
F: +61 3 8420 8900  
[www.essearch.com](http://www.essearch.com)